

Read the instructions carefully. These instructions apply to the LED veranda AB sets. The remote control is supplied complete (including 2x 1.5V batteries, bracket and mounting material).

This manual in your own language?
Or do you need a different variant?
Scan the QR code.






First of all, check that all components are present and test the set before final installation. Switch off the power before working, make sure you have a torch, combination pliers and a suitable screwdriver.




Remove the rotary/pushbutton from the dimmer by pulling it. Then loosen the nut, and remove the rosette from the dimmer.



The terminal block is now accessible. In the right L and in the 0 come the supply wires. Connect the brown wire to the right L and the blue wire to the 0. On the left side, we connect the descending side. Then connect the black wire to the switch sign (left side). And the brown wire to the left L.

Are the wires properly mounted so that no copper is visible? Then switch the power back on in the distribution board. Then press the shaft of the dimmer to light the LED spots, turn the shaft for the dimmer function. After this check, switch off power again.



Reinstall the cover frame on the LED dimmer and screw the bolt onto the thread. Press the round push and turn button onto the metal rotary shaft.

You can now dim the lights with the rotary dimmer Atlas.

